



RUN YOUR SWING GATE ON SOLAR POWER

SETTING UP YOUR SWING GATE SOLAR PANEL SYSTEM

USING 24V SOLAR PANEL:




USING 2 x 12V SOLAR PANELS:



WHAT YOU WILL NEED:

- 2 x 12V Solar Panel or 24V Solar Panels
- 2 x 12V 17Ah Batteries
- 24V Solar Controller



Please note: You will need to use minimum 17Ah batteries.