

Safety Step user instructions

All users are required to read the following instructions even though they may feel familiar with the use and operation of this product. Please retain these instructions for future reference.

Safety step description:

Code: SSR002
250kg Maximum load rating
Orange plastic dome step stool
Non-Slip rubber feet
High grip tape



Please read all instructions carefully before using this product

Inspection:

- Inspect Safety Step after delivery and before each use to confirm condition and operation of all parts. Never use or step on damaged Safety step.
- Visually check the Safety Step is not damaged and is safe to use before operating.
- If Safety Step is being used in an industrial or high use environment, Safety Step will require periodic inspection.
- Keep Safety Step clean and free from dirt, grease oil, paint or any other slippery materials.
- Never use Safety Step if rubber feet or high grip tape is either damaged or worn. Replace as necessary.
- All items must be in good working order, never make temporary repairs of damaged or missing items.

Care & Storage:

- Store in a safe, dry place out of the weather.
- Keep clean and free of all foreign material.
- Regularly examine for any damaged, worn or missing parts.
- Do not store in direct sun light

How to use your Safety Step:

- Never use Safety Step outside its intended purpose, as a support, tool or machine support.
- Never leave Safety Step unattended where it can become a trip hazard or accessed by children.
- Do not use Safety Step if you tire easily, are subjected to fainting spells, or are using medicine, or drugs, or alcohol or by persons with reduced physical, sensory or mental capabilities.
- Do not place Safety Step on unstable bases or stack multiple steps to gain additional height.
- Be mindful of operating location, doorways, pedestrians and vehicles.
- The Safety Step is designed for single person use only, but will comfortably include material and tools. Do not exceed the maximum load rating of 250kg.
- Ensure Safety Step is placed carefully and operated on a firm level surface.
- Use Safety Step with appropriate fully enclosed footwear that is slip resistant. Ensure footwear is clean and in good condition.
- You must be directly facing the Safety Step whenever ascending or descending.
- Do not over-reach. Keep your body centred with both feet firmly planted on the Safety Step.